



WARNING: This product may contain steel alloyed with trace amounts of lead and other elements which are known to the State of California to cause reproductive harm and cancer. For more information, go to www.P65Warnings.ca.gov.To prevent exposure, do not alter the product by welding, grinding, etc.





Cutter & Lock Stud Lock deprimed case in shell holder with the lock stud. Insert pilot into case with pin in flash hole and rotate until it stops cutting. If no metal is removed, case does not need trimming. Hex shank can be installed in drill to spin case.

**Chamfer tool** Insert pointed end of tool into case neck. Turn tool to chamfer. Insert case neck into open end of tool. Turn to chamfer the O.D.

**Primer Pocket Cleaner** Insert appropriate end of primer pocket cleaner into flash hole. Rotate primer pocket cleaner to remove residue from the pocket.

## **Power Grip Shell Holder**

1. Slide push pin into power grip shell holder, o-ring end down first, push down so it is flush with top.

push pin power grip adapter



2. Thread appropriate knurled shell holder onto power grip adapter until snug.


knurled shell holder power grip

adapter



3. Verify knurled shell holder is snug. Depress small or large tray adapter insert, install power shell holder adapter assembly.

depress clear adapter to install



th de le

www.leeprecision.com